

PowerTap: Direct fusebox power pickups let you collect power easily from the fuse box.

The labelled picture is of a Micro2 PowerTap. Other sizes have the same configuration.

Position A takes the vehicle's original fuse.

Position B takes your fuse to protect the new circuit you are creating

Find a fuse not already carrying a heavy load, or an empty fuse slot that is live when the ignition is off and plug in the PowerTap. It should be tail down to make sure you pick up the live connection correctly.

If there is a fuse present, take it out, insert it into the PowerTap in position A; Insert your own fuse in position B.

