

TF2218/7TP for Pickups and Tipppers

Potted for external fitting
All outputs by wire



Input signalwires, power wires
and C2 twin, sleeved 2 metres
Wire in cab.

Output wires, 7-core 0.75mm²
5 metres

**TF2218/7TP
with Twin for
C2 (Buzzer)**

Signal input wires
all 2.1metres long
fully sleeved

Yellow	LH indicator
Blue	Foglight
White	Earth to chassis
Green	RH indicator
Brown	RH tail
Red	Brakes
Black	LH tail
Grey	Reverse

Orange	+12V (fuse 10 amps)
Orange	+12V (fuse 10 amps)

Twin wire	
Black	C2
Black/white	C2 return
	Check polarity

**TF2218/7TP
with Twin for
C2 (Buzzer)
Potted**

Output wires 0.75mm²
in place of screw terminals
5 metres long
fully sleeved.
Wire to trailer socket

Yellow	LH indicator	Pin
Blue	Foglight	1
White	Earth	2
Green	RH indicator	3
Brown	Reverse	4
Red	Brakes	8
Black	BOTH LH and RH tail	6
		7

NOTE:
Brown output is for reverse
Black is for both sidelights
Put a loop in the socket
between pins 5 and 7

DO NOT remove the fuse connectors from the 2 orange
power wires.

To wire reverse on a twin 7-pin
installation, bring the brown wire
across to the 12S socket and
wire it to 12S Pin 1.
On a 13-pin installation, wire
brown to Pin 4.

Quality – Service – Innovation

Unit 1, Chadwick Block, Bracewell Ave Poulton-le-Fylde, Lancashire, FY6 8JF, Phone: 01253 881008 (Fax: 01253 886434)

(www.rydertowing.co.uk mail@rydertowing.co.uk)

Doing so will void any warranty on the relay.

The 2 x 10A fuses are needed alongside an external 15A
fuse for circuit protection on the TF2218/TPH relay.