## SP8601 Caravan Door Retainer Release



For caravans with lever type retainer

Allows you to release the caravan door from the anti-slam securing device without having to lean round or step outside



The device is fitted between the release lever and a hook inside the door



Push the release bar onto the lever. Take the cord across to the door and push it through the hinged side to reach the hook inside.



Hang the closed end of the cord on the hook that you have stuck to the door frame in a suitable place.

The flexible cord will not be damaged by the door closing.

To release the door, simply pull on the cord. It can remain on the hook while you pull